



WATERPROOF MICROPHONE USER GUIDELINES

Read these instructions carefully before using this product. Failure to observe proper use could result in voiding your warranty.



Identifying Your Waterproof Microphone

Look for the “**W**” (for Waterproof) as part of the model number on the white tag located near the end of the mic cable.

Using Your Waterproof Microphone

The IP 57 waterproof rating is intended to protect the microphone element from damage due to conditions such as water, sweat, and makeup. If you experience a temporary change in the microphone performance during use, check that water is not blocking the microphone aperture. Sound waves cannot pass through water so you must clear whatever is blocking the mic aperture. Similarly, think of this in terms of other possible obstructions such as makeup, dirt, etc., where the blockage must be cleared to continue use. You may clear water blockage by gently shaking out the water, and allowing the microphone to air dry.

WHEN TO USE A WINDSCREEN

To achieve consistent performance, the windscreen is highly recommended in heavy water usage where it is expected that water will very likely flood the aperture.



Do **NOT** apply heavy or hot air pressure for drying as this can cause damage.

Caring for Your Waterproof Microphone

- Use a damp soft cloth to clean the microphone from earpiece to the end of the boom to remove sweat, tape residue, or dirt after each use.
- Allow the microphone to thoroughly dry before storing.
- Store the microphone in its provided storage box or other protective enclosure.

The IP 57 rating of your microphone applies to the mic element only— **NOT** the terminating connector or your wireless beltpack.